Ice-Maker Tee Instructions

- 1. Determine whether you have access to your refrigerator from the sink.
- 2. Shut off the incoming water pressure into the water filter housing.
- 3. Disconnect the blue faucet tubing from the **OUTLET** fitting in the stainless steel housing.
- 4. Cut a short (2"-3") of 1/4" tubing. Be sure to use a sharp blade and make a square cut.
- Insert one end of the short section of tubing into the OUTLET fitting by pressing until you feel resistance. At this point the tubing is NOT fully inserted. Push firmly until the tubing is inserted as far as it will go.
- 6. Connect the "tee" fitting to the other end of the short section of tubing. It doesn't matter which of the three openings is used.
- 7. Reconnect the blue faucet tubing into one end of the tee.
- 8. Connect the 1/4" tubing from the refrigerator/ice maker to the third end of the tee.
- 9. Restart the water pressure to the water filter housing. Check for leaks before resuming normal usage of the filter system.



7251 Cathedral Rock Drive, Las Vegas, NV 89128 702.360.8880 • www.multipure.com